


Model Packer 3S Manual Tape Dispenser



Packer 3S OPERATING MANUAL

**BETTER
PACKAGES[®]**

255 Canal Street Shelton, CT 06484
Web Site: www.betterpackages.com

BP P/N: MAN-P3S-OPR

File Name: Packer 3S Manual Rev03.doc

This manual is a non-controlled document.

Information in this manual does not constitute a warranty of performance. Furthermore *Better Packages* reserves the right to revise this publication and make changes from time to time, in its content.

***Better Packages* ASSUMES NO LIABILITY WHAT SO EVER FOR ANY LOSSES OR DAMAGES INCURRED AS A RESULT OF INFORMATION CONTAINED IN THIS MANUAL**

Proprietary Notice

This publication contains information proprietary and confidential to Better Packages. Any reproduction, disclosure, or use of this publication is expressly prohibited except as Better Packages may otherwise authorize in writing.

Better Packages

255 Canal Street

Shelton, CT 06484

Telephone: 800/237-9151

Web Site: <http://www.betterpackages.com>

TECHNICAL DATA

Size: 14 ½" L x 6" W x 6" H

Tape Style: Reinforced and Non-Reinforced Water Activated Tapes

Tape Width: 1" to 3"

Maximum Roll Size: 7 inches diameter

Tape Lengths Dispensed: Unlimited

Shipping Weight: 6lbs. 9oz.

All specifications subject to change without notice

UNPACKING

When unpacking your new Better Pack manual tape dispenser, check to make sure you have the following items before discarding packing material:

- One Packer 3S unit
- Cutting Knife & bridge plate
- Two thumb screws
- Water Tank
- Brush

Note: Remove all packing material before using machine.

PACKER 3S

- Has exclusive subway feed for improved performance.
- For use in reinforced and non-reinforced water activated tape applications.
- For single or multiple rolls.
- Tape width from 1" to 3".
- Can use either gummed-in or gummed-out tapes.

Note: DO NOT USE SUBWAY FEED WITH GUMMED-OUT TAPE

Directions for use:

To Fill Tank

1. Remove lid and brush from tank.
2. Fill tank to ½" from top.
3. Thoroughly wash brush in warm soapy water before initial use.
4. Replace brush into tank.

To Load Tape

1. Unroll 15 inches of tape (see figure 1).
2. Place tape in tape cradle and be sure tape divider is in proper position to fit width of tape.
3. Insert tape-end in back of two rollers. Push the tape through the underside of the dispenser until the end comes out in front of the tape cradle (see figure 2).
4. Thread the tape-end between the knife and bridge plate and out over the brush (see figure 3 & 4).




Figure #1



Figure #2



Figure #3




Figure #4

To Set for Two Rolls

1. Lift forward end of tape divider plate from slot and the rear portion of the dispenser and place in the desired slots that correspond with the width of your two rolls of tape. Combination of widths: 2", 1 ½" and 1" (see figure 5).



Figure #5

To Operate

1. Press tape against back of bridge plate and feed a short piece (see figure 6).
2. Pull tape out in a slightly downward direction to insure thorough moistening (see figure 7).
3. Draw out tape and tear off desired length (see figure 8).




Figure #6




Figure #7




Figure #8

Suggestions for Maintenance

1. Keep the tank two thirds full for best moistening. Check water level to insure satisfactory moistening of tape.
2. Clean brush with soap and rinse once a week to eliminate adhesive build-up.
3. Remove cutting knife and bridge plate monthly for cleaning. Unscrew thumb screw on each side of the blade.
4. Periodically lubricate rolling bearing with a drop of light oil to insure smooth and efficient operation.
5. The tank is easily removed for cleaning. Unsnap the bridge plate and cutter knife at sides and remove; then lift off tank. To re-assemble hook tank into position and snap on bridge plate with the serrated cutting lip towards the front of the machine (see figure 9, 10, 11).



Figure #9




Figure #10



Figure #11

Thank you for Choosing Better Packages.

Better Packages, Inc. Warranty Information

Limited Warranty Statement

The manufacturer warrants each new Better Packages machine and accessory to be free from defects in material and workmanship under normal and proper use, its obligation under this warranty being limited to replacing or repairing any defective parts within the time period indicated for the specific model after delivery (at the company's discretion) to the customer. Wearable parts such as shear blades, springs, water brushes and motor brushes are not covered under the warranty. Machines used for any reason not intended by the manufacturer will not be considered for warranty protection.

The company will replace or repair (at the company's discretion) any defective parts within the warranty period, on a no-charge basis. The Authorized Distributor/Service Center will furnish, without charge, within the time period indicated for the specific model, necessary labor to service the machine.

If customer wishes, they may forward their machine (excluding case sealers) with authorization to Better Packages or an Authorized Distributor/Service Center for warranty service. Any item shipped for warranty service must be shipped in the original factory carton and properly packed with the original protective packaging inserts or a secure carton that will properly protect the unit during transit. Units received improperly packed are subject to costs associated with damage caused during transit. These costs will be the responsibility of the customer. All associated shipping or freight costs related to items shipped for service are the sole responsibility of the customer.

For service under this warranty, call or write your nearest Better Packages Distributor/Service Center or Better Packages, Inc. Shelton, CT at 800-237-9151. Transportation charges on machines or parts returned to Better Packages for service must be prepaid by the customer. Customers will be responsible for freight expenses on parts or machines returned to them.

Product Warranty*

Model	Parts	Labor
Better Pack® 755 Series	2 Years	6 Months
Better Pack® 754 Series	2 Years	6 Months
Better Pack® 555e series	2 Years	6 Months
Better Pack® 500 series	2 Years	6 Months
BP Sealmaster® 3000 CS & 3000 AFF	1 Year	6 Months
Better Pack® 333 Series	2 Years	6 Months
TapeShooter® 150	2 Years	6 Months
TapeShooter® 404	2 Years	6 Months
Packer® 3S	2 Years	6 Months
Better Pack® PS2A	1 Year	6 Months

***When servicing a Better Packages product, genuine Better Packages replacement parts should be used. Any other parts used will void all existing warranties and any UL, CE and CSA certifications and may create a safety hazard.**

Visit www.betterpackages.com to locate your local Authorized Distributor/Service Center

This warranty statement dated January 1, 2007 supersedes all other prior published statements.

